



NOTE:

- 1) IN CUL-DE-SACS, LOCATE THE BLOWOFF 5' FROM SADDLE. PROVIDE ADJUSTMENT, OR CONCRETE PAD AS REQUIRED BY STANDARD DRAWING 3-4.
- 2) CATCH BASIN PER STANDARD DETAIL 5-1 WITH OPEN BOTTOM (2' MIN SECTION) ON COMPACTED TOP COURSE.

2" BLOWOFF ASSEMBLY



**CITY OF
WEST RICHLAND**

DRAWN BY: AFW
CHECKED BY: RSC

DATE: 8/06
REVISION: 7/10

4-1

DRAWING NO.